Call forwarding activated: your calls are forwarded.

Silent mode: your phone neither rings, beeps nor vibrates

Vibration alert: your phone vibrates, but neither rings nor

Call forwarding activated: your calls are forwarded.

Silent mode: your phone neither rings, beeps nor vibrates.

1.2 Idle screen icons()

Battery charge level.

Alarm clock programmed

Level of network reception

Battery charge level

Alarm clock programmed

Voicemail message arrived

Level of network reception

Vibration and ringtone alert.

Unanswered calls

In ONE TOUCH 132:

In ONE TOUCH 232:

one touch 132 one touch | 232

Ouick Start Guide

For more information about how to use the phone, please go to www.alcatelonetouch.com to download complete user manual (English version only). Moreover, from the website you can also consult FAO (English version only).



This product meets applicable national SAR limits of 2.0 W/kg. The specific maximum SAR values can be found on page 16 of this When carrying the product or using it while

worn on your body, either use an approved www.sar-tick.com accessory such as a holster or otherwise maintain a distance of 1.5 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.



Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones recommended by TCT Mobile Limited and its affiliates

alcatelone touch.

Contacts...... 21 (1) [2] (2)

Specific letters (accent) will increase the size of the

SMS, this may cause multiple SMS to be sent to

To access contacts from the idle screen, press the \(\cap \) key and

Select the contact in which you wish to create a file, press the

From the main menu select "Messaging" to create text

message. You can type a message, and you're also able to insert

message, select "Options" to access all the messaging options.

You can save your messages that you send often to "Drafts"

a pre-defined message from "Templates". While writing a

"Options" softkey, select "Add contact" then ...

4.1 Consulting your contacts

select the (1)\(\big(\frac{1}{2}\)\(\)icon from the menu.

4.2 Adding a contact

5.I Create SMS

Call log (\$(1) (2)

Your mobile.....

ONE TOUCH 232

ALCATEL

(2 voc) (3 cet

(4 cm) (5 m) (6 mo)

Menu/Confirm an option

O Navigation key :

Profiles 🔺

Alarm

Calendar -

Create message

ONE TOUCH 132

ALCATEL

3 (2 ASC) (3 DEF

(4 on) (5 m) (6 m)

PORS B TUV SWAYZ

∅*∘₃ □+ #--∳

(Idle screen)

Lock (press and hold)

Power on/Power off

Deactivate the Torch

ONE TOUCH 132 only.

ONE TOUCH 232 only.

Send call

Right softkey

Silence alert (1)

O Voicemail

You can access your call memory by pressing _ from the idle screen, or press the key and select the 200 key icon from

FM Radio fa⁽¹⁾

Your phone is equipped with a radio (3) with RDS functionality. You can use the application as a traditional radio with saved channels or with parallel visual information related to the radio program on the display if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

Alarm (2)

Your mobile phone has a built-in alarm clock with snooze feature.

I.I Keys

0 +

Navigation key Confirm an option (press the middle of the key) Send call

Access call log (idle screen) Power on/off the handset (press and hold)

End call Return to idle screen Left softkey

Right softkey Dial the voicemail number (press and hold) 1 00

> From idle screen - Press: enter zero - Press and hold: enter the symbol "+/P/W" In Edit mode:

- Press: access the symbol table (words mode) input "0" (number mode)

From idle screen

- Press and hold: Lock keypad in idle screen In Edit mode

- Press: change input methods - Press and hold: switch languages

-- (1)\ # -- (2) From idle screen - Press:

> - Press and hold: Silent mode on/off() Activate/deactivate the vibrator (2)

In Edit mode - Press input a space

From idle screen - Press: dial '5'

- Press and hold: switch on/off the torch

Tools.....

the function of your choice in order to customise your telephone:

Phone settings, Call settings, Call control, Network, Security,

Hold down the $\# - {}^{(i)} \backslash \# - {}^{(i)}$ key to get the decimal point. Confirm

Once you enter this menu, there is a monthly-view calendar for you

to keep track of important appointments, etc. Days with events

All the callers in the black list will be automatically blocked when this

mode is on. You are allowed to add 20 contacts to the list from the

Contacts or to add the unwanted numbers directly

ONE TOUCH 132 only. The icons and illustrations in this guide are provided for information ONE TOUCH 232 only

To light in darkness, you may activate "Torch" by below operations:

In idle screen, press and hold 5 & key to activate the Torch light; press we key or Press and hold see key to deactivate it.

Your ALCATEL ONE TOUCH phone includes a game. Select "Game settings", it allows you to manage settings, in which you may set background audio and vibration alert.

Your mobile phone has a built-in alarm clock with snooze feature.

Getting started.....

2.1 Set-up

Removing and installing the back cover



Removing and installing the battery



Inserting and removing the SIM card



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, push it and slide it out.

Latin input mode...

letter or a sequence of characters associated with a key. Press

the key several times until the desired letter is highlighted.

When you release the key the highlight character is inserted

Predictive with the Zi mode: this mode speeds up the writing

of your text. Write the word by pressing a key between 2 ABC

and 9xxx. Press the key once and the word will be modified

each time you press a key. As you go on, the word will keep

changing. Example: For "Tomorrow", press on the following

8 TUV, 6 MNO, 6 MNO= Too -> 6 MNO -> 7 PORS -> Tomorrow

With this menu, you may personalise ringtones for different events

Contact your network operator to check service availability.

To write messages, there are two writing methods:

Charging the battery



Connect the battery charger to your phone and mains socket

- · The charging may take about 20 minutes to start if the
- Be careful not to force the plug into the socket.
- · Make sure the battery is correctly inserted before connecting the charger.
- The mains socket must be near to the phone and easily accessible (avoid electric extension cables).
- When using your telephone for the first time, charge the battery fully (approximately 3 hours). You are advised to fully charge the battery (m (1) \ [1] (2).
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; reduce the backlight time, etc.



The charge is complete when the animation stops.

2.2 Power on your phone

Hold down the 2 key until the phone powers on.

2.3 Power off your phone

(I) ONE TOUCH 132 only.

ONE TOUCH 232 only

Hold down the $\stackrel{\checkmark}{=}$ key from the main screen.

Contact your network operator to check service availability

Safety and use.....

We recommend that you read this chapter carefully before using your phone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

· TRAFFIC SAFFTY:

Given that studies show that using a mobile phone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit. **Services.....** headset...), drivers are requested to refrain from using their mobile when the vehicle is not parked.

> When driving, do not use your phone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some

When switched on, your phone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem

do not place your phone on top of the dashboard or within an airbag deployment area.

- Normal: this mode allows you to type a text by choosing a check with your car dealer or the car manufacturer to make sure that the
 - dashboard is adequately shielded from mobile phone RF energy. CONDITIONS OF USE: You are advised to switch off the telephone from time to time to optimise its

Switch the phone off before boarding an aircraft.

Switch the phone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use. mobile telephones can interfere with other electrical or electronic devices, or equipment using radio frequency.

Switch the phone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any potentially explosive atmosphere.

When the phone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the device, if any.

To avoid hearing impairment, pick up the call before holding your phone to your ear. Also move the handset away from your ear while using the "handsfree" mode because the amplified volume might cause hearing damage.

Do not let children use the phone and/or play with the telephone and accessories without supervision.

When replacing the cover please note that your phone may contain substances that could create an allergic reaction.

discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow the instructions to avoid problems such as tendinitis, carpal

Always handle your phone with care and keep it in a clean and dust-free Do not allow your phone to be exposed to adverse weather or

environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc). The manufacturer's recommended operating temperature range is -10°C to +55°C

Over 55°C the legibility of the phone's display may be impaired, though this is temporary and not serious.

Calls

Dial the desired number then press the \ key to place the

call. If you make a mistake, you can delete the incorrect digits

If your phone is covered by the network, dial emergency

number and press the \(\subseteq \text{key to make an emergency call. This} \)

works even without a SIM card and without typing the PIN

When you receive an incoming call, press the _ key to talk

During a call, you can use contacts, short messages, etc.

3.1 Making a call

by pressing the right softkey.

Making an emergency call

code or unlocking the keypad.

3.3 Receiving a call

and then hang up using the $\stackrel{\text{$\sim$}}{=}$ key.

without losing your correspondent.

To hang up the call, press the $\stackrel{\circ}{\sim}$ key.

3.2 Calling your voicemail (1

To access your voicemail, hold down the | oo key.

3.4 Available functions during the call

Emergency call numbers may not be reachable on all cellular networks. You should never rely only on your phone for emergency calls.

Do not open, dismantle or attempt to repair your mobile phone yourself. Do not drop, throw or bend your mobile phone.

Do not paint it. Use only batteries, battery chargers, and accessories which are

recommended by TCT Mobile Limited and its affiliates and are compatible with your phone model TCT Mobile Limited and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries

Remember to make back-up copies or keep a written record of all important information stored in your phone.

Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your phone or enabling a flashing-lights feature on your phone.

Parents should monitor their children's use of video games or other features that incorporate flashing lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:

Do not play or use a flashing-lights feature if you are tired or need sleep

- Take a minimum of a 15-minute break hourly
- Play in a room in which all lights are on.

13

- Play at the farthest distance possible from the screen.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.

When you play games on your phone, you may experience occasional tunnel syndrome, or other musculoskeletal disorders.

2012-8-22 14:37:09

12

(I) ONE TOUCH 132 only (2) ONE TOUCH 232 only.

English - CIB25L0ALAAA

your recipient.

ONE TOUCH 132 only. ONE TOUCH 232 only

> The quality of the radio depends on the coverage of the radio station in that particular area.

ONE TOUCH 132 only ONE TOUCH 232 only

10.1 Calculator

10.2 Calendar

entered will be marked

10.3 Blacklist

with the key or the left softkey.

ONE TOUCH 132 only

(2) ONE TOUCH 232 only.

ONE TOUCH 132 only

into the text.





IP4343_132_232_QG_Eng_GB_15_120822.indd 1

BATTEDV.

Before removing the battery from your phone, please make sure that the phone is switched off

Observe the following precautions for battery use:

- Do not attempt to open the battery (due to the risk of toxic fumes and
- Do not puncture disassemble or cause a short-circuit in a battery
- Do not burn or dispose of a used battery in household rubbish or store it
- at temperatures above 60°C Batteries must be disposed of in accordance with locally applicable

environmental regulations. Only use the battery for the purpose for which it was designed. Never use damaged batteries or those not recommended by TCT Mobile Limited and/or its affiliates



This symbol on your telephone, the battery and the accessories means that these products must be taken to collection points at the end of their life: - Municipal waste disposal centres with specific hins for these

items of equipment - Collection hins at points of sale

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries: These collection points are accessible free of charge.

All products with this sign must be brought to these collection points In non European Union jurisdictions

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities: instead they are to be taken to collection points for them to be

- 1) Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical area where your phone is used,
- 2) Connection to any equipment not supplied or not recommended by TCT Mobile Limited.
- 3) Modification or repair performed by individuals not authorised by TCT Mobile Limited or its affiliates or your
- 4) Inclement weather, lightning, fire, humidity, infiltration of liquids or foods, chemical products, download of files, crash, high voltage, corrosion, oxidation...

Your phone will not be repaired in case labels or serial numbers (IMEI) have been removed or altered.

There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty provided by your country or jurisdiction.

In no event shall TCT Mobile Limited or any of its affiliates be liable for indirect, incidental or consequential damages of any nature whatsoever, including but not limited commercial or financial loss or damage, loss of data or loss of image to the full extent those damages can be disclaimed by law.

Some countries/states do not allow the exclusion or limitation of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE DISPOSE OF LISED RATTERIES ACCORDING TO THE INSTRUCTIONS

Mains powered chargers will operate within the temperature range of: 0°C

The chargers designed for your mobile phone meet with the standard for safety of information technology equipment and office equipment use. They are also compliant to the ecodesign directive 2009/125/EC. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose

RADIO WAVES Proof of compliance with international standards (ICNIRP) or with European

Directive 1999/5/EC (R&TTE) is required of all mobile phone models before they can be put on the market. The protection of the health and safety for the user and any other person is an essential requirement of these standards

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines. The guidelines were developed by an independent scientific organization (ICNIRP) and include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2.0 W/kg. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the ICNIRP guidelines for this device model are:

ONE TOUCH 132:

Maximum SAR for this mod	del and conditions under which it v	vas recorded.
Head SAR	GSM 900	1.01 W/kg
Body-worn SAR	GSM 900	0.609 W/kg

ONE TOUCH 232-

Maximum SAR for this model and conditions under which it was recorded.			
Head SAR	GSM 900	1.01 W/kg	
Body-worn SAR	GSM 900	0.609 W/kg	

My phone turns off by itself Troubleshooting..... · Check that your keypad is locked when you are not using

Before contacting the service centre, you are advised to follow the instructions below:

- You are advised to fully charge () \(\big| \) the battery for optimal operation
- Avoid storing large amounts of data in your phone as this may affect its performance Use User Data Format to perform phone formatting, (to
- perform User Data format, hold down # while simultaneously pressing the power on/off key under the power off mode). ALL User phone data: contacts, messages and files will be lost permanently.

and carry out the following checks:

My phone cannot switch on

22

- Check the battery contacts, remove and reinstall your battery, then turn your phone on
- Check the battery power level, charge for at least 20 minutes
- If it still does not work, please use User Data Format to reset the phone (3)

My phone is frozen or has not responded for several

- Restart your phone by pressing and holding the
 key
- Remove the battery and re-insert it, then restart the phone
- If it still does not work, please use User Data Format to reset the phone (3)

During use, the actual SAR values for this device are usually well below the values stated above. This is because, for purposes of system efficiency and to nize interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value.

Body-worn SAR testing has been carried out at a separation distance of 1.5 cm. To meet RF exposure guidelines during body-worn operation, the device should be positioned at least this distance away from the body. If you are not using an approved accessory ensure that whatever product is used is free of any metal and that it positions the phone the indicated distance away from

Organizations such as the World Health Organization and the US Food and Drug Administration have stated that if people are concerned and want to reduce their exposure they could use a hands-free device to keep the phone away from the head and body during phone calls, or reduce the amount of me spent on the phone. For more information you can go to www.alcatelonetouch.com

Additional information about electromagnetic fields and public health are available on the following site: http://www.who.int/peh-emf. Your telephone is equipped with a built-in antenna. For optimal operation,

vou should avoid touching it or degrading it. As mobile devices offer a range of functions, they can be used in positions other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or USB data cable. If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the phone at least 1.5 cm away from the

 $eZiText^{TM}$ and Zi^{TM} are trademarks of ZieZiText™ Corporation and/or its Affiliates. 71 corporation

your phone, and make sure power off key is not mis-contacted

If it still does not work, please use User Data Format to reset

Make sure you are using an ALCATEL ONE TOUCH battery

Make sure your battery is inserted properly before plugging in

Make sure that your battery is not completely discharged; if

the battery power is empty for a long time, it may take around

20 minutes to display the battery charger indicator on the

Make sure charging is carried out under normal conditions

When abroad, check that the voltage input is compatible

Verify the network coverage with your operator

Try selecting the available network(s) manually

Check with your operator that your SIM card is valid

Try connecting at a later time if the network is overloaded

My phone cannot connect to a network or "No service"

due to unlocking keypad.

Check the battery charge level

My phone cannot charge properly

Clean the battery contact if it's dirty

Try connecting in another location

and the charger from the box

the charger

(0°C to +40°C)

is displayed

23

Regulatory information...

The following approvals and notices apply in specific regions as noted

ONE TOUCH 132-

17

Invalid SIM card

scratched



TCT Mobile Europe SAS - Siège social : 55 Avenue des Champs Pierreux, Immeuble Le Capitole 92000 Nanterre Franc

· Make sure the SIM card has been correctly inserted

Make sure the service of your SIM card is available

network is not overloaded or unavailable

Unable to receive incoming calls

Make sure you have not barred outgoing calls

For international calls, check the country and area codes

network (check for overloaded or unavailable network)

Make sure you have not forwarded incoming calls

Make sure that you have not barred certain calls

Your caller has concealed his/her name or number

Make sure your SIM card is not broken

Make sure your SIM card is inserted properly

Import all contacts stored in SIM card to phone

Check your subscription status with your operator (credit,

The caller's name/number does not appear when a call

· Check that you have subscribed to this service with your

Make sure your phone is connected to a network, and the

Check your subscription status with your operator (credit,

Unable to make outgoing calls

SIM card valid, etc.)

SIM card valid, etc.)

I cannot find my contacts

is received

operator

Make sure the chip on your SIM card is not damaged or

ONE TOUCH 232:



McLean, Virginia, United States CE 1588 TCT Mobile Europe SAS

TCT Mobile Europe SAS - Siège social : 55 Avenue des Champs Pierreux, Immeuble Le Capitole 92000 Nanferre France SAS au capital de 23 031 072 euros - RCS Nanterre B 440 038 222 - Sivel 440 038 222 000 38 APE 4652Z

The sound quality of the calls is poor

You can adjust the volume during a call by pressing the \$\display\$ key Check the network strength dill

Make sure that the receiver, connector or speaker on your phone is clean

I am unable to use the features described in the manual

- Make sure you have dialed a valid number and press the \ Check with your operator to make sure that your subscription includes this service
 - Make sure this feature does not require an ALCATEL ONE TOUCH accessory

When I select a number from my contacts, the number cannot be dialed

- Make sure that you have correctly recorded the number in your file
- Make sure that you have inputted the country prefix when Make sure your phone is switched on and connected to a calling a foreign country

I am unable to add a contact in my contacts

- Make sure that your SIM card contacts are not full; delete some files or save the files in the phone contacts (i.e. your professional or personal directories
- My callers are unable to leave messages on my voicemail Contact your network operator to check service availability
- I cannot access my voicemail Make sure your operator's voicemail number is correctly
- entered in "Messaging\Voicemail" Try later if the network is busy

25

- The flickering (1)\ (2) icon is displayed on my standby
- You have saved too many short messages on your SIM card; delete some of them or archive them in the phone memory

General information......

- Internet address: www.alcatelonetouch.com
- Hot Line Number: see "TCT Mobile Services" leaflet or go to our Internet site.

On our Internet site, you will find our FAO (Frequently Asked Questions) section. You can also contact us by e-mail to ask any questions you may have.

An electronic version of this user guide is available in English and other languages according to availability on our server: www.

Your telephone is a transceiver that operates on GSM networks with 900 and 1800 MHz hands

C€1588

This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The entire copy of the Declaration of Conformity for your telephone can be obtained through our website: www.alcatelonetouch.com

Protection against theft "

Your telephone is identified by an IMEI (phone serial number) shown on the packaging label and in the product's memory. We recommend that you note the number the first time you use your telephone by entering * # 0 6 # and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen. This number allows your mobile telephone to be blocked preventing a third person from using it, even with a different SIM card

Disclaimer

There may be certain differences between the user manual description and the phone's operation, depending on the software release of your telephone or specific operator services.

TCT Mobile shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the operator exclusively.

(I) Contact your network operator to check service availability.

SIM card PIN locked

· Contact your network operator to obtain the PUK code (Personal Unblocking Key)

How to make your battery last longer

- Make sure you follow the complete charge time (minimum 3
- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication
- Switch on the backlight upon request

Telephone warranty

Your phone is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months (1) from the date of purchase as shown on your original invoice.

Batteries (2) and accessories sold with your phone are also warranted against any defect which may occur during the first six (6) months (1) from the date of purchase as shown on your original invoice.

In case of any defect of your phone which prevents you from normal use thereof, you must immediately inform your vendor and present your phone with your proof of purchase.

If the defect is confirmed, your phone or part thereof will be either replaced or repaired, as appropriate. Repaired Phone and accessories are entitled to a one (1) month warranty for the same defect. Repair or replacement may be carried out using reconditioned components offering equivalent functionality.

This warranty covers the cost of parts and labor but excludes

This warranty shall not apply to defects to your phone and/or accessory due to (without any limitation):

- The warranty period may vary depending on your country
- The life of a rechargeable mobile phone battery in terms of conversation time standby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your phone during the first six months after purchase and for approximately 200 more recharges.

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

All rights reserved © Copyright 2012 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice

ONE TOUCH 132 only

User Data Format ALL user phone data: Contacts, messages and files will be lost permanently. Please store phone data in SIM card before you want to format

ONE TOUCH 232 only.

IP4343_132_232_QG_Eng_GB_15_120822.indd 2 2012-8-22 14:37:12

